

SEASIDE CASUAL FURNITURE

ENVIRO WOOD

(38) Kingston Chaise rev. A

Parts List:

- (1) Chaise Body Assembly
- (2) Leg Stretchers
- (2) Rear Legs (Wheel Holes)
- (2) Front Legs
- (2) Wheels



Hardware:

- (8) 2-3/4" Connector Bolts
- (2) 3-1/2" Connector Bolts
- (4) 3" Hex 1/4" Lags
- (8) Lock Washers
- (14) Flat Washers
- (8) Nuts
- (2) 1/4" Nylon Nuts

Tools Required:

- 7 /16 Socket or Wrench
- 4MM Allen Wrench (Included)

Assembly Instructions


Step One: Set Up

READ ENTIRE INSTRUCTIONS BEFORE BEGINNING! Carefully remove contents from box. Make sure that all parts and hardware are included.

Step Two: Rear & Front Leg Assemblies



Place Chaise Body Assembly face down on a clean flat surface. Place Rear Legs inside Chaise Body Assembly, while aligning pre-drilled holes. Rear Legs have to holes extra for Wheels. Attach using (2) 2-3/4" connector bolts, flat & lock washers and nuts (Left Picture). Repeat process on other side and for Front Legs (Right Picture).



Step Three: Leg Stretcher Assembly



Place Leg Stretcher in between both Rear Legs. Attach using (1) 3" Hex 1/4" Lags (Left Picture). Repeat process on other side and for Front Legs.

Step Three: Wheel Assembly

Place Wheels against the outside of the Rear Legs and align with pre-drilled holes. Attach using (1) 3-1/2" connector bolt. Place a flat washer on each side of the Wheel and inside of Rear Leg. Install (1) 1/4" Nylon Nut. Finger tighten and make sure Wheel will turn freely or loosen till Wheel will turn freely. Repeat process on other side.

